

ORIGINAL INSTRUCTIONS

Instruction Manual
Digital Flow Controller for Air
PFCA7## series

The intended use of the digital flow controller for air is to monitor and control flow and provide an output signal.

1 Safety Instructions

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of "Caution," "Warning" or "Danger." They are all important notes for safety and must be followed in addition

to International Standards (ISO/IEC) *1), and other safety regulations. *1) ISO 4414: Pneumatic fluid power - General rules and safety

requirements for systems and their components.

ISO 4413: Hydraulic fluid power - General rules and safety

requirements for systems and their components IEC 60204-1: Safety of machinery - Electrical equipment of machines

- Part 1: General requirements ISO 10218-1: Robotics - Safety requirements - Part 1: Industrial robots.

Refer to product catalogue, Operation Manual and Handling Precautions for SMC Products for additional information.

• Keep this manual in a safe place for future reference.

A Danger	Danger indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.
A Warning	Warning indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.
▲ Caution	Caution indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.

Marning

- Always ensure compliance with relevant safety laws and standards.
- All work must be carried out in a safe manner by a qualified person in compliance with applicable national regulations.
- This product is class A equipment intended for use in an industrial environment. There may be potential difficulties in ensuring electromagnetic compatibility in other environments due to conducted or radiated disturbances.
- Refer to the operation manual on the SMC website (URL: https://www.smcworld.com) for more safety instructions.

2 Specifications

2.1 General specifications

2.1	General specifications				
	Item	Specifications			
	Enclosure	IP40 (IEC 60529)			
ent	Operating temperature	Operating: 0 to 50 °C : Storage: -10 to 60 °C (no freezing or condensation)			
nu	Humidity range	35 to 85% R.H. (no condensation)			
≣nvironment	Withstand voltage	1000 VAC for 1 min. between terminals and housing			
E	Insulation resistance	50 MΩ min (500 VDC Mega) between terminals and housing			
Materials in contact with fluid		PPS, FKM, SUS, Brass, PTFE, Si, Au, GE4F			

2 Specifications (continued)

2.2 PFCA7## specifications

2.2	2.2 PFCA7## specifications							
Мо	del		PFCA710	PFCA725		PFCA711		
Fluid	Applicabl		Dry air / N ₂ / Ar / CO ₂ (Air quality: JIS B8392-1 1.1.2 to 1.6.2, ISO8573-1 1.1.2 to 1.6.2)					
т.	Fluid tem range	perature		0 to 50 °C				
	Detection method			Heating ty	pe sensor			
	Rated	Dry air,	0.1 to 10	0.1 to 10 0.2 to 25 0.5 to 50 1 to 10				
	control flow rate	N ₂ , Ar	L/min 0.1 to 5	L/min	L/min	L/min 1 to 50		
	range *2	CO ₂	L/min	0.2 to 12.5 L/min	0.5 to 25 L/min	L/min		
		Dry oir	0.04 to	0.1 to	0.2 to	0.4 to		
	Set	Dry air, N ₂ , Ar	10.3	25.8	51.5	103		
	controlled flow rate	3 -	L/min 0.04 to	L/min 0.1 to	L/min 0.2 to	L/min 0.4 to		
	range *2	CO ₂	5.15	12.9	25.8	51.5		
			L/min	L/min	L/min	L/min		
Flow	Min. unit	of set I flow rate	0.01 L/min		0.1 L/min			
_			0.0 to					
	range	mulated flow	99,999,9 99.9 L	0 to	999,999,99	99 L		
		ated flow rate	0.1 L		1 L			
		ated volume (Pulse width).1 L / Pulse		1 L / Pulse		
	Accumula hold func	ated value tion		Select every 2 or 5 minutes (when the function is not set, power supply OFF reset)				
	Control a	ccuracy		±3%				
	Analogue			±3%	FS			
-	accuracy		±1% F.S.					
	Repeatability Temperature							
	characteristics		±5% F.S. (0 to 50 °C, Reference: 25 °C)					
က္	Pressure characteristics		±2% F.S. (Operating pressure range, reference operating pressure)					
Control *3			Reaches within Reaches within					
Son			±3%F.S. of the commanded flow commanded flow					
Ŭ	Settling ti	me	rate in rate in					
				ds or less		d or less		
			(under reference conditions) *5 conditions) *					
	Control s	pec. method	IO-Link, local setting, analogue input					
	Operation		F			(NLC))		
	power su disconne	• • •	Fully closed (Normally closed (N.C.))					
Ħ	2.55511110	Input type	1 to 5 V					
inpu	Voltage	Input	1 MΩ approx.					
ane		impedance						
alog	Current	Input type Input		4 to 2	!0 mA			
An	Janont	impedance		250 Ω	or less			
put		Output type	Se	elect 1 to 5	V or 0 to 10) V		
outh	Voltage	Output		1 kΩ a	pprox.			
Analogue output Analogue input		impedance Output type			:0 mA			
alog	Current	Load						
An		impedance	50 to 600 Ω					
	Output ty	ре		N or PNP				
	Output m	ode	accumula output,	deviation tated output error output	, accumula t, switch ou	ted pulse utput off		
ont	Switch or		Selec	t normal or	reversed c	output		
outp	Max. load				mA	_ _		
Switch output		lied voltage		30 VDC (I	NPN only)			
Swi	(Residua			r less (at 80 less, varia				
	Delay tim			0.01 s in	crements			
	Protectio	n	Switch output power supply polarity					

protection, over current protection

2 Specifications (continued)

Мо	Model		PFCA710	PFCA725	PFCA750	PFCA711		
	Operating pressure range *6		50 to 250 kPa	100 to 300 kPa	150 to 300 kPa	250 to 350 kPa		
Pressure	Min. oper differentia	Min. operating differential pressure *7		100 kPa	150 kPa	250 kPa		
Pre	Reference	ce operating	100 kPa	150 kPa	200 kPa	300 kPa		
	Withstan	d pressure		1 M	1Pa			
al		upply voltage		24 VD0	C ±10%			
Electrical	Current o	consumption		200 mA	or less			
Е	Protection	n			olarity prote			
	Reference	ce condition*10	r	normal cond	ondition (S dition (NOR	(a)		
	Display mode		Seled	Instantaneous flow rate display (Main display) Select set control flow display or accumulated flow rate display (Sub display)				
	Instantaneous flow			L/mir	n, cfm			
ay	Units *11	Accumulated flow	L, ft ³					
Display	Display- able	Instantaneous flow	-0.5 to 10.5 L/min	-1.3 to 26.3 L/min	-2.5 to 52.5 L/min	-5 to 105 L/min		
	range	Accumulated flow	0 to 99,999,9 99.9 L	9,999,9 0 to 999,999,999 L		99 L		
	Min. display	Instantaneous flow	0.01 L/min	0.1 L/min				
	units	Accumulated flow	0.1 L	1 L				
	Display*	12	LCD (The display screen can be rotated by 90, 180, and 270°)					
Мо	unting ori	entation			t be mounte cing down	ed with the		
	Piping sp	pecification	C4 (\phi4) / C6 (\phi6)	C6 (\phi6) /	Ν7 (φ1/4")	/ C8 (\phi8)		
Piping	Screw fitting		01 (Rc1/8) F1 (NPT1/8) N1 (G1/8) (Rc F (NPT			02 (Rc1/4) F2 (NPT1/4) N2 (G1/4)		
ıt	Product	With One- touch fitting		255 g a	approx.			
Weight		With Screw fitting		305 g a	approx.			
	Lead wir		180 g approx.					
	Mounting Bracket		et 25 g approx.					

- *1: Refer to the recommended pneumatic circuit.
- *2: The operation may be unstable outside the rated control flow range.
- *3: Applicable fluid: The specification value when dry air is shown. For gas types other than air, the value is for reference.
- *4: For the analogue voltage, option 1, lead wire with M12 connector (3 m long), is used. If the lead wire is different, the accuracy may fluctuate depending on the wiring resistance.
- *5: The reference conditions are as follows: pressure: reference operating pressure; temperature: 25°C; commanded flow rate: step change from 1% to 100%. In other conditions, the setting time may be delayed.
- *6: The operating pressure range refers to the pressure that can be applied to the primary side of the product. This product cannot be used for negative pressure.
- *7: The minimum operating differential pressure is the minimum differential pressure value (pressure difference between the primary and secondary sides) required for the product to operate normally.
- Do not mount a restrictor immediately on the secondary side of the product. Doing so may result in unstable control operation.
- *8: Pressure on the secondary side of the product is open to atmosphere (0 kPa).
 *9: Analogue output and switch output are not included. If there is no supply pressure, a consumption current beyond the product specifications may flow in the event of an error in control operation.
- *10: Standard condition (STD): 20 °C, 101.3 kPa, 65% R.H. (The flow rate given in the specification is the value at the standard condition) Normal condition (NOR): 0 °C, 101.3 kPa, 0% R.H.
- *11: This setting is only available for models with the units selection function. For models without the units selection function, the instantaneous flow is fixed to L/min and the accumulated flow (rate) is fixed to L.

2 Specifications (continued)

*12: Typefaces included herein are solely developed by DvnaComware Taiwan Inc. *13:SMC are working to improve quality. However, any products with tiny scratches,

*13:SMC are working to improve quality. However, any products with tiny scratches, smear, dead-pixel, or variation in the display colour or brightness which does not affect the performance of the product, are verified as conforming products.


2.3 Cable specifications (ZS-53-A, ZS-53-D)

Conductor	Nominal cross section	AWG21
Inquilator	Outside diameter	1.60 mm approx.
Insulator	Colours	Brown, White, Black, Blue
Chaoth	Material	Oil resistant PVC
Sheath	Outer diameter	ф6

2.4 Characteristics data


• Flow rate / Analogue input

Analogue input values are converted into corresponding commanded flow rates.



			С			
	Α	В	PFCA710 / 750 / 711	PFCA725	D	Е
Voltage input	1 V	1.016 V	1.04 V	1.032 V	5 V	5.12 V
Current input	4 mA	4.064 mA	4.16 mA	4.128 mA	20 mA	20.48 mA

• Flow rate / Analogue output



		A		
	0 L/min	PFCA710 /	PFCA725	В
		750 / 711	FI CA723	
Voltage output (1 to 5 V)	1 V	1.04 V	1.032 V	5 V
Current output	4 mA	4.16 mA	4.128 mA	20 mA
•				

		С		
	0 L/min		PFCA725	D
Voltage output (0 to 10 V) *1	0 V	0.1 V	0.08 V	10 V

*1: Set the current that flows from the connected equipment to the analogue output to 20 μA or less when selecting 0 to 10 V. When more than 20 μA current flows, the accuracy may not be satisfied below 0.5 V.


Model	Min. rated control flow rate	Max. rated control flow rate
PFCA710	0.1 L/min	10.0 L/min
PFCA725	0.2 L/min	25.0 L/min
PFCA750	0.5 L/min	50.0 L/min
PFCA711	1.0 L/min	100.0 L/min

Marning

• Special products (-X) might have specifications different from those shown in this section. Contact SMC for specific drawings.

3 Name and function of parts

• PFCA7## body



Item	Description		
Display	Refer to the details below.		
Piping port	For piping connections. IN represents "inlet" and OUT represents "outlet".		
Connector	For lead wire with M12 connection.		
UP button DOWN button	Use these buttons to select the mode and the display shown on the Sub display, or increase or decrease the numerical value. The assignment of the UP and DOWN buttons changes depending on the display rotation angle.		
SET button	Use this button to change the mode and to set a value.		

Display



Item	Description		
Main display	Displays the flow rate value and the error codes.		
Sub display	Displays the commanded flow rate, peak/bottom value, accumulated flow rate value, switch output / communication mode, and line names.		
Reference condition	Indicates the reference condition currently selected.		
Display units	Indicates the units currently selected.		
Icon display	Displays the function status. See below.		

· Icon display

Icon	Name	Description
<mark>₽</mark>	Key-lock	The Icon is ON when the buttons are locked.
OUT	OUT status	The Icon LED is ON when the output is ON.
Ana-In	Analogue input status	Red: Analogue input warning (less than –5%). Green: Analogue input normal. Yellow: Analogue input warning (above 110%).
◇	IO-Link status	Yellow: Communicating with IO-Link. White: Connecting to IO-Link (including communication disruption). Light is OFF: Not connected to IO-

For more information about IO-Link communication status indication refer on the SMC to the operation manual website (URL: https://www.smcworld.com).

4 Installation

4.1 Installation

Marning

- Do not install the product unless the safety instructions have been read and understood.
- · Use the product within the specified operating rated flow, operating pressure and temperature range.
- Tighten to the specified tightening torque.
- If the tightening torque is exceeded the mounting screws, brackets and the product can be broken. Insufficient torque can cause displacement of the product from its correct position.
- Do not drop, hit or apply excessive shock to the product.

4.2 Environment

M Warning

- Do not use in an environment where corrosive gases, chemicals, salt water or steam are present.
- Do not use the product in a place where it could be splashed by oil or chemicals
- Do not use in an area where electrical surges are generated.
- Do not use in an explosive atmosphere.
- Do not install in a location subject to vibration or impact in excess of the product specifications.
- Do not use the product in the presence of a magnetic field.
- Do not mount in a location exposed to radiant heat that would result in temperatures in excess of the product specifications.
- Do not use the product in an environment that is exposed to temperature cycles.
- Do not expose to direct sunlight. Use a suitable protective cover.

4.3 Mounting

- Refer to the flow direction marked on the product before mounting.
- Never mount the product in a location that will be used as a foothold.
- Mount the bracket (SMC Part number ZS-40-L for side mounting or ZS-53-G for flow path mounting) to the product using screws supplied.
- The tightening torque of the bracket mounting screws must be 0.63 ±10% N•m.
- When the product is mounted using a bracket, use M3 screws (4 pcs.).
- Refer to the operation manual on the SMC website (URL: https://www.smcworld.com) for mounting dimensions.


- The product should be flushed out by air blow to remove any dust left in the piping before connecting the piping.
- Do not mount the product with the display facing downward.
- Do not insert metal wires or other foreign matter into the piping ports. This can damage the sensor causing failure or malfunction.
- If there is a risk of foreign matter entering the fluid, install a filter or mist separator on the IN side (entry side) to avoid failure or malfunction.
- If the fluid flow on the IN side (entry side) of the product is unstable, correct measurement and flow rate control will not be possible. If a valve is used on the IN side (entry side) of the product, the flow may be disturbed due to the change of the effective area.
- Do not install a restrictor immediately on the product OUT side (outlet). Otherwise, the flow control action may be unstable.

⚠ Caution

- Before connecting piping make sure to clean up chips, cutting oil, dust
- When installing piping or fittings, ensure sealant material (tape) does not enter inside the port.
- When connecting the piping, hold the specified part of the body with a spanner. Using a spanner on other parts may damage the product. Specifically, make sure that the spanner does not damage the
- The required tightening torque of the fittings is given in the table below

4 Installation (continued)

- If the tightening torque is exceeded, the product can be damaged. If the correct tightening torque is not applied, the fittings may become
- Ensure there is no leakage after piping.



Nominal thread size	Required torque
Rc(NPT)1/8	7 to 9 N•m
Rc(NPT)1/4	12 to 14 N•m

Nominal thread size	Width across flats of attachment	
Rc(NPT)1/8, Rc(NPT)1/4, G1/8	17 mm	
G1/4	21 mm	

5 Wiring

5.1 Wiring


A Caution

- Wiring should only be performed with the power supply turned OFF.
- Confirm proper insulation of wiring.
- Avoid repeatedly bending, stretching or applying a heavy object to the lead wire.
- Use separate routes for the product wiring and any power or high voltage wiring. Otherwise, malfunction may result due to noise.
- Keep wiring as short as possible to prevent interference from electromagnetic noise and surge voltage.
- If a commercially available switching power supply is used, be sure to ground the frame ground (FG) terminal. If a commercially available switch-mode power supply is connected for use, switching noise will be superimposed and it will not be able to meet the product

In that case, insert a noise filter such as a line noise filter/ferrite between the switching power supplies or change the switching power supply to a series power supply.

5.2 M12 Connector Pin numbers (ZS-53-A, ZS-53-D)





When used as a switch output device

Pin number	Wire colour	Name	Description
1	Brown	DC(+)	24 VDC
2	White	OUT2	Analogue output
3	Blue	DC(-)	0 V
4	Black	OUT1	Switch output
5	Grey	IN	Analogue input

When used as an IO-I ink device

Pin number	Wire colour	Name	Description
1	Brown	DC(+)	24 VDC
2	White	NC	Not connected
3	Blue	DC(-)	0 V
4	Black	C/Q	Communication data (IO-Link)
5	Grey	NC	Not connected

5 Wiring (continued)

5.3 Connecting

- Align the lead wire M12 connector (SMC part number ZS-53-A) with the connector key groove and insert vertically.
- Connection is complete when the knurled part is fully tightened. Check that the connection is not loose.

6 Outline of Settings

Power is supplied




The flow rate control action and each output are forced to turn OFF for 3 seconds after power is supplied. The SMC logo appears.



[Measurement mode]

Measurement mode is the condition where flow control and the switch operation are performed.


This is the basic mode; other modes should be selected for setpoint changes and other function settings.



Refer to the operation manual on the SMC (URL: https://www.smcworld.com) for further setting details.

7 Function selection mode

- In this mode, each function setting can be changed separately.
- In measurement mode, press the SET button for between 2 and 4 seconds, then select [Function] to enter function selection mode.
- Press the UP or DOWN button to change the number and each function that you want to change can be selected.





Press the

SET button

F0 function setting







F1 function setting

F99 function setting Page 2 of 3

7 Function selection mode (continued)

. When setting is complete:

Press the UP or DOWN button to select [Back], to return to function selection mode.

Press the SET button for at least 2 seconds to return to measurement mode.

Defectly a efficient

7.1 Default settings

No	Function	Item	Default setting	
		[Fluid] Fluid settings	[Air] Air	
		[Fluid cond] Flow rate	[STD] Standard	
		reference condition.	condition	
		[Unit] Flow rate display units.	[L/min] L/min (L)	
[[0]	System	[I/O type] NPN or PNP		
[F0]	settings	output selection.	[PNP] PNP output	
		[IO-Link] IO-Link enable/disable setting.	[Enable] Enable	
		[PD invalid] Output PD	[Shut off]	
		setting during communication error.	Output PD: 0	
			[Tolerance] Limit	
		[Mode] Output mode selection	deviation tolerance mode	
	OUT4	[tol(P1)] Limit deviation	[3 %] 3% of rated	
[F1]	OUT1 settings	tolerance setting	control flow	
	3	[OnDelay1] ON delay time setting	[0.00 s] 0 second	
		[OffDelay1] OFF delay time setting	[0.00 s] 0 second	
[F10]	Measurement setting	[Resolution] Display resolution setting	[Low] 100 resolution	
	· · · · · · · · · · · · · · · · · · ·		[1-5V] 1 to 5 V	
		[Type] Analogue output	(Analogue voltage type).	
		switching setting	[4-20mA] 4 to 20 mA	
[F22]	Analogue output	0 0	(Analogue current	
[1 22]	settings		type).	
	3	[Free span] Analogue	[10.00L/min] 10 L/min (For the PFCA710,	
		free range setting	the upper limit of the	
			rated control flow.)	
		[Save intvl]	[No covel Nette held	
		Accumulation storage setting		[No save] Not to hold
	Accumulated	[Disp mode]	[Increment] Addition	
[F30]	flow (rate)	Accumulated display	direction	
	settings	direction setting [Auto shut]		
		Automatic accumulation	[Disable] Disable	
		shut-off enable/disable		
	Display settings	[Colour]	[1onB,offR] ON: Blue;	
		Select measurement value display colour	OFF: Red	
		[Display] Display OFF	[ON] Diaplay ON	
		setting	[ON] Display ON	
[F80]		[Rotation] Display rotation angle setting	[0deg] Rotation angle 0°	
		[Brightness] Screen	[100%] Brightness	
		brightness setting	100%	
		[Line name] Line name display setting	[OFF] No line name displayed	
[F81]	PIN code setting	Selection of PIN code	[OFF] Not used	
[F91]	Device information	-	Information check (No settings)	
[F96]	Input check	-	Input check (No settings)	
[F98]	Output	_	[Normal] Normal	
[1 30]	check	-	output	
	Reset to factory			
[F99]	default	-	[oFF] Not to be reset	
	settings			
	settings			

8 IO-Link Parameter settings

8.1 IODD file

IODD (I/O Device Description) is a definition file which provides all properties and parameters required for establishing functions and communication of the device.

- The IODD includes the main IODD file and a set of image files such as vendor logo, device picture and device icon.
- The IODD file for this product is as follows:

Product number	IODD file *
PFCA7**-**-**	SMC-PFCA7**-**-yyyymmdd-IODD1.1

- *: "*" indicates the product model which corresponds to each IODD file.
- *: "yyyymmdd" indicates the date of creation of the file, with yyyy, mm, and dd representing the year, month, and date, respectively.
- The IODD file can be downloaded from the SMC website (URL: https://www.smcworld.com).

8.2 IO-Link specifications

IO-Link type	Device	
IO-Link version	V1.1	
Communication speed	COM2 (38.4 kbps)	
Min. cycle time	5.5 ms	
Process data length	Input Data: 8 bytes, Output Data: 2 bytes	
On request data communication	Available	
Data storage function	Available	
Event function	Available	

9 Other Settings

- Reset operation
- Zero clear function

For further details refer to the operation manual on the SMC website (URL: https://www.smcworld.com).

10 How to Order

Refer to the operation manual or catalogue on the SMC website (URL: https://www.smcworld.com) for How to order information.

11 Outline Dimensions (mm)

Refer to the operation manual or catalogue on the SMC website (URL: https://www.smcworld.com) for Outline Dimensions.

12 Troubleshooting

12.1 Error display

	Error name	Error display	Description	Measures	Control operation during an error
	System error (Err 0, 4, 6, 8, 16, 40, 82, 83)	Err () System error	An internal data error has occurred.	Turn off the power and check for any noise source, and then turn on the power again. If the failure cannot be solved, contact SMC.	Stop
	Over current error (Err 1)	Out1 over current	The switch output load current has exceeded 80 mA.	Remove the cause of the excessive current in the output.	Continuino
	Zero clear error (Err 3)	Err 3 Zero clear out of range	During a zero clear operation, a flow rate exceeding ±5%F.S. is applied.	Perform the zero- clear operation again when the flow rate is not applied.	Continuing
-	Version does not match (Err 15)	Err 15 10-Link version error	The IO-Link version does not match with the master.	Align the master IO-Link version to the device.	Continuing
	Control error (Err 50)	Err 50 Control error Control error Reset: © and © > 1e *: When [Local] is selected	The controlled flow rate does not continuously reach the commanded flow rate for at least 5 seconds.	Use the product within the operating differential pressure and operating pressure range. Check to see if there is any air leakage from piping, etc. The controlled flow rate is restored by setting the commanded flow rate to zero. When [Local] is selected in control selection setting mode, the controlled flow rate is restored by pressing and holding the UP and DOWN button for 1 second or longer.	Stopped
	Close error (Err 51)	Err 51 Close error	Flow rate exceeding ±5% F.S. is applied when commanded flow rate is less than ±1% F.S.	Mount the product so that the fluid flow direction is the same as the arrow indicated on the side of the body.	Stopped
	Abnormal power supply voltage (Err 60)	Power supply error	Power supply voltage is outside of the range 24 VDC±10%.	Supply a power supply voltage within the range 24 VDC±10%.	Stopped

Refer to the operation manual or catalogue on the SMC website (URL: https://www.smcworld.com) for Troubleshooting details.

13 Maintenance

13.1 General Maintenance

A Caution

- Not following proper maintenance procedures could cause the product to malfunction and lead to equipment damage.
- If handled improperly, compressed air can be dangerous.
- Maintenance of pneumatic systems should be performed only by qualified personnel.
- Before performing maintenance, turn off the power supply and be sure to cut off the supply pressure. Confirm that the air is released to atmosphere.
- After installation and maintenance, apply operating pressure and power to the equipment and perform appropriate functional and leakage tests to make sure the equipment is installed correctly.
- If any electrical connections are disturbed during maintenance, ensure they are reconnected correctly and safety checks are carried out as required to ensure continued compliance with applicable national regulations.
- Do not make any modification to the product.
- Do not disassemble the product, unless required by installation or maintenance instructions.
- How to reset the product after a power cut or when the power has been unexpectedly removed

The settings of the product are retained from before the power cut or de-energizing.

The output condition also recovers to that before the power cut or deenergizing, but may change depending on the operating environment. Therefore, check the safety of the whole system before operating the product.

14 Limitations of Use

14.1 Limited warranty and Disclaimer/Compliance RequirementsRefer to Handling Precautions for SMC Products.

15 Product disposal

This product should not be disposed of as municipal waste. Check your local regulations and guidelines to dispose of this product correctly, in order to reduce the impact on human health and the environment.

16 Contacts

Refer to <u>www.smcworld.com</u> or <u>www.smc.eu</u> for your local distributor/importer.

SMC Corporation

URL: https://www.smc.eu (Europe) SMC Corporation, 1-5-5, Kyobashi, Chuo-ku, Tokyo 104-0031, JAPAN Specifications are subject to change without prior notice from the manufacturer.
© SMC Corporation All Rights Reserved.

Template DKP50047-F-085O