
# **CXSW Series** 96, 910, 915 920, 925, 932




# Construction

### CXSWM/Slide bearing



# CXSWL/Ball bushing bearing



\* The numbers correspond with those in the "Construction" of the CXSW series in the Best Pneumatics catalog.

### **Seal Kit List**

| No. | Description | Material | Note   |
|-----|-------------|----------|--|
| 20  | Piston seal |          |  |
| 21) | Rod seal    | NDD      | 23 is a non-replaceable part, so it is not included in the seal kit. |
| 22  | O-ring      | NBR      |  |
| 23  | O-ring      |          | in the sear kit.   |

Replacement Parts: Seal Kit

| riepiacement i arts. Cear Kit |            |             |  |  |  |
|-------------------------------|------------|-------------|--|--|--|
| Bore size (mm)                | Part no.   | Contents    |  |  |  |
| 6                             | CXSWM6-PS  |             |  |  |  |
| О                             | CXSWL6-PS  |             |  |  |  |
|                               | CXSWM10-PS |             |  |  |  |
| 10                            | CXSWL10APS |             |  |  |  |
| 15                            | CXSWM15-PS |             |  |  |  |
| 15                            | CXSWL15APS | Set of nos. |  |  |  |
| 20                            | CXSWM20-PS | 20, 21, 22  |  |  |  |
| 20                            | CXSWL20APS |             |  |  |  |
| 25                            | CXSWM25-PS |             |  |  |  |
| 20                            | CXSWL25APS |             |  |  |  |
| 20                            | CXSWM32-PS |             |  |  |  |
| 32                            | CXSWL32APS |             |  |  |  |

- \* The seal kit includes 20 to 22. To order them, use the order number given in the above table.
- \* Since the seal kit does not include a grease pack, it should be ordered separately.

Grease pack part no.: GR-S-010 (10 g)

Modular F.R.L. Pressure Control Equipment