
Vertical Return Filter FHBA Series



The vertical return filters are designed for mounting directly on top of oil tanks for hydraulic systems. They prevent dust generated within the circuit from entering the tank and help keep the oil clean. This efficient configuration reduces the total number of filters required.



Compact design that does not clutter the top of the oil tank

Since most of the filter case is inside the oil tank, very little space is occupied on the top of the tank.

No need for an OUTLET pipe

The filter case also functions as a fluid return pipe, so there is no need to attach a separate OUTLET pipe.

Easy maintenance

Simply open the cover and extract the element from the top of the filter. Replacement is quick and easy.

Designed to prevent collected dust from falling into the oil tank

The collected dust remains inside the element, so it cannot flow out when the relief valve is opened and all collected dust is removed from the case.

Two INLET ports

The filter has two INLET ports, oriented 180° from each other to provide more flexibility when routing pipes.



Specifications

opeoinioution		
Operating pres	sure	Max. 1.6 MPa
Operating tem	perature	Max. 80°C
	Cover	Aluminum die-cast
Main material	Body	Aluminum die-cast
	Case	Steel plate
	O-ring/Seal	NBR or FKM Note)
	Material	Paper, Stainless steel, Carbon steel, Aluminum, Epoxy resin
Element	Nominal filtration *	5, 10, 20 μm
	Differential pressure resistance	0.6 MPa
Differential pressure indicator operating pressure (Element replacement differential pressure)		0.18 MPa
Relief valve op	en pressure	0.25 MPa

Relief valve open pressure

* Micromesh elements with other than the standard filtration are available.

* The paper elements for water-glycol is 10 µm only.

Note) The material of the O-rings differs depending on the hydraulic fluid used. Petroleum, Water-glycol, Emulsion: NBR; Phosphoric ester: FKM

Model/Rated Flow Rate


Model	Port size (Rc)	Max. flow rate (L/min)	Weight (kg)	Applicable hydraulic fluid
FHBAD-06	3/4	150	1.7	N : Petroleum
FHBAD-10	1 1/4	300	3.7	W: Water-glycol Emulsion
FHBAD-12	1 1/2	400	5	V : Phosphoric ester

The symbol represented by
indicates the type of applicable hydraulic fluid (N, W, V).

Accessory/Ontion


Description	Part no.	Note
Differential pressure indicator	CB-58H	Petroleum, Water-glycol, Emulsion
Differential pressure indicator	CB-58H-V	Phosphoric ester
Differential pressure indication switch	CB-59H	Petroleum, Water-glycol, Emulsion
(N.C. and N.O. common)	CB-59H-V	Phosphoric ester
Blanking cap	AG-12H	Petroleum
(for differential pressure indication	AG-12H-W	Water-glycol, Emulsion
part)	AG-12H-V	Phosphoric ester

Flow Rate Characteristics



SMC

How to Order



Port size Micromesh Pape (Nominal size) 5 µm 10 µm 20 µm 5 µm 10 µm 20 µm 06 (3/4^B) EP001H-005N EP001H-010N EP001H-020N EM601H-005N EM601H-010N EM601H-020N 10 (1 1/4^B) EP101H-005N EP101H-010N EP101H-020N EM701H-005N EM701H-010N EM701H-020N


 10 (11,4/8)
 EP101H-005N
 EP101H-020N
 EM701H-005N
 EM701H-010N
 EM701H-020N
 a76 x 190

 12 (11,4/8)
 EP201H-005N
 EP201H-010N
 EP201H-020N
 EM801H-005N
 EM801H-010N
 EM801H-020N
 o76 x 190

 Note 1) The symbol at the end of the element part no. indicates the hydraulic fluid type. N: Petroleum, Phosphoric ester, W: Water-glycol, Emulsion.
 Emulsion.

Note 2) Above elements require one element per filter.

Construction/Seal List



When actuating relief valve

SMC

Replacement O-ring/Seal List (Only 1 O-ring is required per filter for options (1, 3), (4), and (5) below; however, for option (2), 2 seals are required.)

Port size	Applicable hydraulic fluid		 O-ring order no. 	② Seal order no.	③ O-ring order no.	④ O-ring order no.	⑤ O-ring order no.
	,		(Nominal size)		(Nominal size)	(Nominal size)	(Nominal size)
06	Petroleum.	NBR	KA00465	AL-206H	KA00463	KA00465	KA00470
00	Water-glycol, -70		(G80)	AL-20011	(G65)	(G80)	(P28)
10 to 12		-1	KA00453	AL-207H	KA00793	KA00453	KA00244
10 10 12	Emulsion		(G105)	AL-20/11	(G85)	(G105)	(P42)
06		FKM-70	KA00702	AL-206H-V	KA00614	KA00702	KA00717
00	Phosphoric ester		(G80)	AL-20011-V	(G65)	(G80)	(P28)
10 to 12	i nospriolic ester	EPDM-70	KA00688	AL-207H-V	KA00703	KA00688	KA00723
101012	101012		(G105)	AL-20/H-V	(G85)	(G105)	(P42)

Note 1) The material of seals (AL-206H-V to AL-207H-V) is EPDM.

Note 2) The material and nominal size notations are based on JISB2401.

Handling Precautions

Element size

ø56 x 180

① Mounting

- Confirm the IN orientation before mounting. Then connect so that the case is oriented downward.
 For maintenance, make sure to provide sufficient space above the filter for removing the element.
- The filter has two IN ports. If one is not used, it must be covered with a plug or the like.

FH

HOW

- Before mounting the filter on the oil tank, confirm that (4) the O-ring (see "Construction") is installed on the body.
- Ensure that the opening in the case (OUT) is always below the fluid surface. Air could leak into the system if the fluid level drops below the outlet opening.

2 Operation


- The hydraulic fluid used becomes high viscosity when the temperature is low during the winter, etc., and the differential pressure indicator or the switch may activate. If this occurs, wait until the oil temperature rises by a warm-up operation, then check if this is caused by clogging.
- Once the differential pressure indicator is triggered, the indicator continues to be displayed until the indicator is reset (by depressing the reset button), even if the pump stops operating. Reset after replacing the element and restarting operation, or after normal operation starts in cold
- weather such as during winter. • When using a differential pressure indication switch and if a filter clogged signal is incorporated into the sequence circuit of the machine, make sure to design the system so the filter clogged signal does not operate until normal operation starts.


③ Element replacement

- When the pressure difference reaches 0.18 MPa during filter operation (actuating the differential pressure indicator), stop operation, and replace the paper element or wash the micromesh element. If the micromesh element has reached the end of its service life, replace it.
- When replacing the element, check the O-rings and replace them if they are damaged.
- When washing the micromesh element, do not wipe it using a stiff brush or rag.


FHBA Series


Dimensions






Mounting base dimensions





Differential pressure indicator



Differential pressure indication switch

															(mm)
Port size Rc (d)	Α	В	С	D	Е	F	G	н	J	ĸ	L	М	Ν	Р	Q
3/4	55	54	76	65	200	299	270	95	100	75	70	M8	12	10	15 or more
1 1/4	75	70	110	00.1	210	342	320	100	100	100	05			10	01
1 1/2	75 76 112 8	75 76 112	75	89.1	310	442	420	120	128	100	95	M10	14	12	21 or more

Differential Pressure Indication

Two indication methods are available: differential pressure indicator and differential pressure indication switch. These can be mounted on all filter models.


Differential pressure indicator

- Operating pressure—0.18 MPa
- Once a value is displayed, it will continue to be displayed until reset, even if the pump is stopped.
- Perform element replacement when the red ring floats up and covers the entire view port.



Differential pressure indication switch

- Operating pressure—0.18 MPa
- When a value has been displayed, it will be automatically reset when the pump is stopped. (Non-reset type)
- This is a visual dual-purpose. Perform element replacement when the switch has actuated (when the red ring floats up and covers the entire view port).
- N.C. and N.O. common



* Refer to page 529 for "Microswitch for differential pressure indication switch".

FH Series Microswitch for Differential Pressure Indication Switch

(1) Contact specifications

Table 1 Contact specifications

Item	Specifications
Inrush current	Max. 15 A
Minimum applicable load	5 VDC 160 mA

(2) Rating

Table 2 Rating


Rated voltage	Resistance load
250 VAC	5 A

(3) Other performance

Table 3 Other specifications

	Item	Specifications			
Insula	tion resistance	100 M Ω or more (Measured by 500 VDC, insulation resistance tester.)			
Conta	act resistance	30 mΩ or less			
	Between terminals with the same pole.	1,000 VAC 50/60 Hz 1 min			
Withstand voltage	Between charged metal	1.500 VAC 50/60 Hz 1 min			
	part and ground	1,500 VAC 50/60 HZ T MIN			
	Between each terminal and	1 500 V/AC 50/60 Up 1 min			
	non-charged metal part	1,500 VAC 50/60 Hz 1 min			

(4) Electric circuit



Precautions

 Connect desired wiring to the micro switch indication symbols 1 (COM.), 2 (N.C.), and 3 (N.O.).

 When a protection mechanism is required, take appropriate considerations on the electric circuit since the micro switch is a type of non-reset.

(5) Terminal type

Soldering terminal

HOW