

RS2H Series 050, 063, 080




Construction

Double acting (DL, DM)







* The numbers correspond with those in the "Construction" of the RS2H series in the Web Catalog.

Seal Kit List

No.	Description	Material	Note	
37)	Piston seal			
38	Rod seal	NDD	38 is a non-replaceable part, so it is not included in the seal kit.	
39	Tube gasket	NBR		
40	O-ring			

Replacement Parts: Seal Kit

D	Part no.			
Bore size (mm)	Double acting	Double acting spring type	Single acting	Contents
50	RS2H50D-PS	RS2H50T-PS		Set of nos.
63	RS2H63D-PS	RS2H63T-PS		37, 39, 40
80	RS2H80D-PS	RS2H80T-PS		<i>‱</i> , ∞, ₩

- * The seal kit includes 37, 39, 40 for ø50 to ø80. Order the seal kit based on each bore size.
- * Since the seal kit does not include a grease pack, it should be ordered separately.

Grease pack part no.: GR-S-010 (10 g)

Replacement Parts: Shock Absorber

Bore size (mm)	Part no.			
50	RS2H-R50			
63	RS2H-R63			
80	RS2H-R80			

