



CXWM Series




ø10, ø16, ø25

Construction

ø10



ø16, ø25



* The numbers correspond with those in the "Construction" of the CXWM series in the Best Pneumatics catalog.

Seal Kit List

No.	Description	Material	Note
20	Rod seal	NBR	22 is a non-replaceable part, so it is not included in the seal kit.
21	Piston seal	NBR	
22	Piston gasket	NBR	
23	Cylinder tube gasket	NBR	

With End Lock

30	Body gasket	NBR	33 and 34 are non-replaceable parts, so they are not included in the seal kit.
31	Rod seal	NBR	
32	Piston seal	NBR	
33	Steel ball	High carbon chrome bearing steel	
34	Steel ball	High carbon chrome bearing steel	
35	O-ring	NBR	

Replacement Parts: Seal Kit

Model	Part no.	Contents
Cylinder body		
CXWM10	CXWM10-PS	Set of nos. 20, 21, 23
CXWM16	CXWM16-PS	
CXWM25	CXWM25-PS	

* The seal kit includes 20, 21, 23. Order the seal kit based on each bore size. (The piston gasket 22 is not replaceable.)

* Since the seal kit does not include a grease pack, it should be ordered separately.

Grease pack part no.: GR-S-010 (10 g)

End lock

CXWM10	CXWM10R-PS	Set of nos. 30, 31, 32, 35
CXWM16	CXWM16R-PS	
CXWM25	CXWM25R-PS	

* The seal kit includes 30, 31, 32, 35. Order the seal kit based on each bore size.


* Since the seal kit does not include a grease pack, it should be ordered separately.

Grease pack part no.: GR-S-010 (10 g)


CXWM Series ø20, ø32

Construction

ø20, ø32



With end lock



* The numbers correspond with those in the "Construction" of the CXWM series in the Best Pneumatics catalog.

Seal Kit List

No.	Description	Material	Note
17	Piston seal	NBR	20 is a non-replaceable part, so it is not included in the seal kit.
18	Rod seal		
19	Cylinder tube gasket		
20	Piston gasket		

With End Lock

12	Body gasket	NBR
13	Rod seal	
14	Piston seal	
15	O-ring	

Replacement Parts: Seal Kit

Model	Part no.	Contents
Cylinder body		
CXWM20	CXWM20-PS	Set of nos. 17, 18, 19
CXWM32	CXWM32-PS	17, 18, 19

* The seal kit includes 17, 18, 19. Order the seal kit based on each bore size. (The piston gasket 20 is not replaceable.)

* Since the seal kit does not include a grease pack, it should be ordered separately.

Grease pack part no.: GR-S-010 (10 g)

End lock

CXWM20	CXWM20R-PS	Set of nos. 12, 13, 14, 15
CXWM32	CXWM32R-PS	12, 13, 14, 15

* The seal kit includes 12, 13, 14, 15. Order the seal kit based on each bore size.

* Since the seal kit does not include a grease pack, it should be ordered separately.

Grease pack part no.: GR-S-010 (10 g)

Actuators

Modular F.R.L.
Pressure Control Equipment

Air Preparation
Equipment

Industrial Filters

Replacement
Procedure

Actuators

Modular F.R.L.
Pressure Control Equipment

Industrial Filters