

# Mini Free Mount Cylinder


## CUJ Series

ø4, ø6, ø8, ø10


The Replacement Procedure is on p. 322

### Construction

#### Double acting



#### Single acting, spring return



\* The numbers correspond with those in the "Construction" of the CUJ series in the Best Pneumatics catalog.

#### Seal Kit List

No.	Description	Material	Note
①	Piston seal	NBR	
⑫	Rod seal		
⑬	Tube gasket		

#### Replacement Parts: Seal Kit

Bore size (mm)	Part no.	Contents
<b>Double acting</b>		
4	CUJB4-PS	Set of nos. ①, ⑫, ⑬, and a grease pack
6	CUJB6-PS	
8	CUJB8-PS	
10	CUJB10-PS	

\* The seal kit ① to ⑬ comes as a set. Use the kit number for each bore size.

#### Single acting, spring return

Bore size (mm)	Part no.	Contents
4	CUJB4-S-PS	Set of no. ① and a grease pack
6	CUJB6-S-PS	
8	CUJB8-S-PS	
10	CUJB10-S-PS	

\* Use the following part number for ordering a grease pack only.

**Grease pack part no.: GR-L-005 (5 g)**

# Mini Free Mount Cylinder


# CUJ Series

ø12, ø16, ø20




## Construction

### Double acting



Without magnet

### Single acting, spring return



Without magnet

\* The numbers correspond with those in the "Construction" of the CUJ series in the Best Pneumatics catalog.

### Seal Kit List

No.	Description	Material	Note
13	Piston seal	NBR	
14	Rod seal		
15	O-ring		

### Replacement Parts: Seal Kit

Bore size (mm)	Part no.	Contents
<b>Double acting</b>		
12	CUJB12-PS	Set of nos. 13, 14, 15, and a grease pack
16	CUJB16-PS	
20	CUJB20-PS	

\* The seal kit 13 to 15 comes as a set. Use the kit number for each bore size.

### Single acting, spring return

12	CUJB12-S-PS	Set of no. 13 and a grease pack
16	CUJB16-S-PS	
20	CUJB20-S-PS	

\* Use the following part number for ordering a grease pack only.

**Grease pack part no.: GR-L-005 (5 g)**

Actuators

Modular F.R.L.  
Pressure Control Equipment

Air Preparation  
Equipment

Industrial Filters

Replacement  
Procedure

Actuators

Modular F.R.L.  
Pressure Control Equipment

Industrial Filters